



PRONTO HIRE

86 Forge Road, Silverdale | P: 09 426 8833 | Free: 0800 77 66 86 | E: hire@prontohire.co.nz

Operating Instructions

Cherry Picker

Steps:

1. Disconnect machine from towing vehicle
2. Remove the two locking pins from the boom
3. Enter activation code. Green light should be lit?
 NO: re-enter code
 YES: continue on to step 4
4. Make sure emergency stops are out on the panel and the one in the platform basket
5. Start machine
6. Level machine by holding down auto level switch, lift enable light **MUST** be on. The level bubble may not be in the middle but you can level a bit more by using individual leg switch (the lift enable light **MUST** be on)
7. Switch both switches from stabiliser to boom and base to platform. If engine cuts out, make sure lift enable light is on and platform emergency stop is out.
8. Enter platform and start operating. Your foot must be on the dead man foot pedal

When finished:

- Make sure basket is facing backwards and all other rams are retracted
- Ensure boom lock pins are in place before towing

